

Sunpak Gripper

Tabletop and Wrap-Around Tripod for Indoor or Outdoor Use

Compact, tabletop and travel tripod with take-anywhere design and bendable aluminum core with foam covering that can wrap around almost any shape and almost any object. The 360° polycarbonate ball head is light, yet strong enough to support any device up to 2.6 lb.

Assembling Your Sunpak Gripper with a Camera (Tabletop Mode):

1. Rotate the Leg Angle Adjustment Ring to change the tripod from Standard Mode to Low Angle Mode.
2. Angle the legs accordingly.
3. Screw your compact camera or camcorder to the 1/4"-20 screw of the ball head of the Gripper. Make sure the ball head is locked by tightening the Ball Head Lock Knob before releasing the camera to insure that it is secure.
4. Adjust the positioning of the camera by utilizing the Ball Head Lock Knob to get the perfect angle.
5. Spread the legs and place on a flat, level surface for tabletop usage.

Assembling Your Sunpak Gripper with a Smartphone (Tabletop Mode):


1. Follow steps 1 and 2 above for camera setup.
2. Screw the smartphone adapter onto the 1/4"-20 screw of the Gripper.
3. To use the smartphone in Portrait mode, loosen the lock on the ball head and move the head into the cut-out of the ball head. Re-tighten the ball head lock.

Assembling Your Sunpak Gripper with a GoPro (Tabletop Mode):

1. Follow steps 1 and 2 above for camera setup.
2. Screw the GoPro to the 1/4"-20 screw of the ball head of the Gripper. Make sure the ball head is locked by tightening the Ball Head Lock Knob before releasing the GoPro to insure that it is secure.
3. Mount your GoPro into the forks of the GoPro mount and use your GoPro tightening screw (not included) to lock your GoPro in place.

Wrapping Your Sunpak Gripper Around an Object:

1. Make sure that the area to which your tripod will be secured is clean, dry and suitable to support the tripod and camera, smartphone or GoPro.
2. To secure your tripod's legs to an object, take each leg of the tripod and wrap it around the item that you intend to mount, making sure that the tripod's foam leg segments make tight contact with the object.
3. You can mount your tripod in any number of ways (see some examples to the right). Or, even use it as a tabletop tripod.
4. The maximum load capacity of 2.6 lb for this tripod is dependent upon surface shape, texture, size and how it is used.



Sunpak Gripper

Tabletop and Wrap-Around Tripod for Indoor or Outdoor Use

Compact, tabletop and travel tripod with take-anywhere design and bendable aluminum core with foam covering that can wrap around almost any shape and almost any object. The 360° polycarbonate ball head is light, yet strong enough to support any device up to 2.6 lb.

Specifications

- Max Height: 11.5" / Min Height: 9.8" / Folded: 12"
- Weight: 10.6 oz
- Max Load: 2.6 lb*
- Head: Ball Head
- Chassis: Polycarbonate with two-position leg angle
- Leg Sections: 1
- Leg Construction: Aluminum core with foam covering
- Feet: Non-marring rubber
- Accessories: Smartphone adapter and GoPro mount
- Warranty: 1 year limited

* Max capacity depends upon how tripod is used and surface texture. Use caution when wrapping legs around an object and test for adequate holding ability prior to releasing device.

Product design and specifications subject to change without notice.

Features

- Designed for compact cameras, smartphones and GoPro
- Bendable aluminum core legs wrapped in high density foam covering
- Bendable to practically any object
- Polycarbonate ball head and chassis are lightweight, yet strong
- Ball head can be set at any angle
- Chassis ring allows for two-level leg angles
- Non-marring and non-slip rubber feet
- Can be used as a handheld tripod by grasping the legs together
- Includes smartphone adapter and GoPro mount

1. Slide the On/Off Switch on the Bluetooth Remote to the "On" position.
2. Turn on your smartphone's Bluetooth function. When you see SUNPAK in your list of Bluetooth devices, pair your phone to that device.
3. Once paired, open up the camera feature of your smartphone.
4. Attach your phone to the mount. The smartphone mount can accept phones up to 3.5" wide.
5. To take a picture, press the Shutter Release button. For Apple (iPhones), press the iOS button. For Android phones, press the Android button.

Note: Some Android users may notice the camera zooming when the Shutter Button on the remote is pressed. If this occurs, please go into your smartphone's camera settings and change the "Volume Key" setting to "Camera". Please refer to your smartphone manual for assistance in changing this setting.

Note: You cannot pair more than one remote to the same smartphone at the same time.



Sunpak One Year Limited Warranty

This Sunpak product has been carefully manufactured, accurately adjusted, inspected and thoroughly tested before shipment to assure you of the highest quality.

Should this product require service, we will repair or replace, at our option, any part or the product itself, which our examination shows to be defective in material or workmanship. This warranty does not apply to wear and tear associated with the normal use of the product. This warranty is non-transferable.

Repairs will be made to the product at no charge, under the terms of the warranty as stated above, only when accompanied by a dated and itemized bill of sale and nominal handling charge.

Be certain to follow all assembly and/or operating instructions with this product. This warranty is not valid if the product has been misused or damaged in any way that is beyond our control or through normal wear and tear associated with use. This warranty applies only to the product and we are not responsible in any way for losses, damages or any inconvenience caused by equipment failure.

Some states do not allow the exclusion or limitation of consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may have other rights which may vary from state to state.

Should service be required, the product should be carefully packed (in the original packaging if possible) and sent, prepaid and insured, along with a check or money order for \$6.95 (shipping and handling), to the address listed below. A note briefly describing the nature of the defect should also be enclosed to expedite handling.

Proof of purchase and payment for shipping and handling must be included for all warranty repairs.

Sunpak, ToCAD America Inc., 53 Green Pond Road, Rockaway, NJ 07866, Attention Service Department

Safety and Precautions

- Ensure that all levers, handles, knobs and leg locks are properly tightened, and that all three legs are fully angled opened before use.
- Do not carry or transport the tripod with a camera, smartphone or other device attached (for example carrying over your shoulder or cradled in your arms).
- Do not Oil or Grease any part of the tripod.
- Do not use any solvents or thinners to clean your tripod. Use mild detergent and wipe dry with a soft, lint-free cloth only.
- Do not store or expose your tripod to excessive heat or cold or use close to any flame or fire.
- Do not exceed the load limit for this product.
- Always keep this product dry. Do not use in the rain or in damp conditions.
- Do not leave or store the unit in temperatures above 120°F (as in being stored in a car on in direct sunlight) to avoid damage to internal parts.